




# ZTE

## MF30 / MF60 Router configuration for Windows


Insert the SIM card (The router comes with a default WPA2 Key. The key exist in a label under the battery)

- Plug in the router
- Open your browser and enter the IP **192.168.0.1**
- Click **Enter**



Enter

- Username: **Admin**
- Password: **admin**






- Enter the pin code: **0000**
- Click **Apply**



- Network Selection window
- Choose your preferred network
- Click **Apply**





Click on APN settings

- Choose **Add**
- **Profile Name: Alfa 3G**
- **APN Settings: Manual**
- **APN: Internet.mic1.com.lb**
- **PDP Type: IP**
- **PDP Settings: Auto PDP**
- **DNS: Auto DNS**
- **Authentication: PAP**
- **Username: mic1**
- **Password: mic1**
- Click **Save**
- Click **Set Default**

The screenshot shows the ZTE 3G Wireless Router WebGUI Configuration interface. The main content area is titled "3G Settings -> APN Settings" and has three tabs: "Wireless Info", "Network Select", and "APN Settings". The "APN Settings" tab is active, displaying a form with the following fields and values:

APN Settings	
Profile Selection	Add new
Profile Name	Alfa 3G
APN Settings	<input checked="" type="radio"/> Auto APN <input type="radio"/> Manual APN
APN	Internet.mic1.com.lb
Dial No.	+998
PDP Type	<input checked="" type="radio"/> ip <input type="radio"/> ppp
PDP Settings	<input checked="" type="radio"/> Auto PDP <input type="radio"/> Manual PDP
DNS	<input checked="" type="radio"/> Auto DNS <input type="radio"/> Manual DNS
Authentication	<input type="radio"/> CHAP <input checked="" type="radio"/> PAP
User Name	mic1
Password	****

At the bottom right of the form, there are buttons for "Save", "Set Default", "Add", and "Delete".



Click **Quick step** form the left menu  
Click **Next**

The screenshot shows the ZTE 3G Wireless Router WebGUI Configuration interface. The left sidebar contains a menu with the following items: Router Status, Quick Setup (highlighted with a red circle), WAN Connection, 3G Settings, Router, Wi-Fi Settings, Firewall, SMS, Advanced, and Logout. The main content area is titled "Quick Setup" and contains the following text: "The wizard will show you how to set up your router in the safe way. Click 'Next' to continue, click 'Back' and 'Next' to navigate, and click 'Apply' to save the settings." Below this, there are "Notes" stating: "Basic parameters can be set in this wizard. For advanced parameters, you need to set them in other menus." A "Next" button is located at the bottom right of the main content area and is circled in red.

**Profile name** should be created by now  
Click **Next**

The screenshot shows the ZTE 3G Wireless Router WebGUI Configuration interface, specifically the "Profile Configuration" screen. The left sidebar contains a menu with the following items: Router Status, Quick Setup, WAN Connection, 3G Settings, Router, Wi-Fi Settings, Firewall, SMS, Advanced, and Logout. The main content area is titled "Quick Setup -> Profile Configuration" and contains the following text: "Profile Name: The default profile that you used currently." "APN: If a fixed APN (Access Point Name) is given by your ISP, select 'Manual APN'; otherwise, select 'Auto APN', the router automatically obtains it." "Dial No: This parameter is provided by your ISP. Dial No. is used for data service connections." Below this, there are several input fields: "Profile Name" (containing "ALFA\_3G" and circled in red), "APN Settings" (with radio buttons for "Auto APN" and "Manual APN"), "APN" (containing "lincenet.micl.com.lb"), and "Dial Settings" (with "Dial No." containing "199#"). A "Next" button is located at the bottom right of the main content area and is circled in red.

## Authentication window

Click **Next**



Quick Setup -> Authentication

• Authentication  
The authentication mode is provided by your Internet Service Provider(ISP).  
Password Authentication Protocol(PAP): It provides a simple method without encryption for the peer to establish its identity using a 2-way handshake.  
Challenge-Handshake Authentication Protocol(CHAP): It is used to periodically verify the identity of the peer User Name and Password are provided by your ISP and used to obtain authentication from the ISP when the connection is established.

Authentication

Authentication  CHAP  PAP

User Name

Password

Back **Next**

## Choose a name for the wireless network

Click **Next**

Quick Setup -> SSID Configuration

•Name SSID(Service Set Identifier) Enter a character string up to 32 characters as the name for your wireless local area network(WLAN).  
•SSID Broadcast  
Enabled: The router broadcasts the SSID and other devices can detect and connect to it.  
Disabled: The router disables broadcasting and hides the name of your network.

SSID

Name(SSID)

SSID Broadcast

SSID Broadcast

Back **Next**



Choose the required encryption

Click **Next**

Quick Setup -> Security Configuration

•Add encryption to your wireless network to prevent unauthorized traffic monitoring and access.  
No Encryption: Your wireless network is open to everyone without authentication and encryption, and this option is not recommended.  
Wired Equivalent Privacy(WEP): It is a 64-bit or 128-bit encryption method with user configurable fixed keys.  
Wi-Fi Protected Access(WPA): It is a 256-bit encryption method with keys changing automatically.  
WPA2: It is the securer version of WPA with implementation of the 802.11i standard.  
WPA Encryption Algorithm: TKIP, AES, TKIP+AES.  
WPA Pre-Shared Key: Enter the Pre-Shared key as a plain text(ASCII) pass-phrase of at least 8 characters.  
Key Rotation Interval: Specify the key update interval in seconds. Enter 0 to disable the update function (You'd better set more than 59)  
Network Key: Enter 5 ASCII characters or 10 hexadecimal digits for a 64-bit key, enter 13 ASCII characters or 26 hexadecimal digits for a 128-bit key.

Encryption Mode  
Encryption Mode: NO ENCRYPTION

Back Next

Verify the settings

Click **Apply**

The **Disconnected** description should become **Connected** and connection to the internet should be established

Quick Setup -> Configuration As Follows

Profile Name	ALFA 3G
Dial No.	998
User Name	root
APN Settings	manual
APN	InternetUNCL.com.br
Authentication	PAP
Name (SSID)	ZTE Wireless Network
SSID Broadcast	enable
Encryption Mode	NO ENCRYPTION

Back Apply