

## **ZTE** – 4G LTE


**MiFi router Installation for Windows** 

#### Insert USIM card

- Turn on the router
- Click on WPS button 2 times to reveal the wireless key
- Connect Laptop to Router
- Open the browser and enter the following address: 192.168.0.1
- Enter the password: admin and click login

Password	-	<b>N</b>	
	<u>&gt;</u>		
Login			
		Login	
	_		

#### Click on Settings






### Choose APN

Home	Information	SD Card	SMS		Phonebook	Settings
Quick Settings	APN					
Network Settings						
<ul> <li>Dial-up Settings</li> </ul>		Current APN	Alfa 3G+			
Network Selection		Mode	Auto  Manual			
		Profile	Alfa 3G+	•		
WI-FI Settings						
Device Settings		PDP Type	IPv4	Ŧ		
Firewall		Profile Name *	Alfa 3G+			
Router Settings		IPv4 APN *	internet.mic1.com.lb			
AP Station		IPv4 DNS Mode	Auto Manual			
	IP	v4 Authentication	NONE	Ŧ		
		IPv4 User Name	mic 1			
		IPv4 Password				

#### Click on Manual, then Add New

Home	Information	SD Card	SMS	Phonebook	Settings
Quick Settings	APN				
Network Settings					
Dial-up Settings		Current APN	Alfa 3G+		
Network Selection		Mode	Auto Manual		
> APN		Profile	Default	Add New	
Wi-Fi Settings					
Device Settings		PDP Type	IPv4		
Firewall		Profile Name *	Default		
Router Settings		IPv4 APN *	Default		
AP Station		IPv4 DNS Mode	Auto Manual		
	1	Pv4 Authentication	NONE	]	
		IPv4 User Name			
		IPv4 Password			



- Profile Name: Alfa LTE
- **IPv4 APN**: usb.mic1.com.lb
- IPv4 Authentication: PAP
- Click APPLY

Home	Information	SD Card	SMS	Phonebook	Settings
Quick Settings	APN				
Network Settings					
<ul> <li>Dial-up Settings</li> </ul>		Current APN	Alfa 3G+		
Network Selection		Mode	Auto @ Manual		
> APN		Profile	Default	Cancel	
WI-FI Settings		PDP Type			
Device Settings				1	
Firewall		Profile Name *	Alfa LTE		
Router Settings		IPv4 APN *	usb.mic1.com.lb		
AP Station		IPv4 DNS Mode	Auto  Manual		
		Pv4 Authentication	PAP	]	
		IPv4 User Name			
		IPv4 Password			
					Apply

#### Under Manual, Choose Alfa LTE

Home	Information	SD Card	SMS	Phonebook	Settings
Quick Settings	APN				
Network Settings					
Dial-up Settings		Current APN	Alfa 3G+		
Network Selection		Mode	Auto Manual		
> APN		Profile	Alfa LTE	Add New	
WI-FI Settings					
Device Settings		PDP Type		•	
Firewall		Profile Name *	Alfa LTE		
Router Settings		IPv4 APN *	usb.mic1.com.lb		
AP Station		IPv4 DNS Mode	Auto  Manual		
		IPv4 Authentication	PAP	•	
		IPv4 User Name			
		IPv4 Password			
				Set as default	Apply Delete

#### Click Set as Default



# Click on **Network Selection**Under Automatic, choose LTE Only



Home	Information	SD Card		SMS	Phonebook	Settings	
Quick Settings	Networ	k Selection					
Network Settings							
<ul> <li>Dial-up Settings</li> </ul>		Network Selection	Automatic	Automatic	•		
> Network Selection			Manual	Automatic 4G Only			
> APN				3G Only 2G Only			
Wi-Fi Settings						Apply	
Device Settings	?						
Firewall							
Router Settings							
AP Station							

#### Dial Up Settings

- Under WAN Connection Mode, choose Automatic
- Wait for few seconds and the connection will be established

Home	Information	SD Card	SMS	Phonebook	Settings
Quick Settings	Dial-up	Settings			
Network Settings					
<ul> <li>Dial-up Settings</li> </ul>	WA	N Connection Mode	Automatic		
<ul> <li>Network Selection</li> </ul>		0	Manual		
> APN	Check	k here, you can connect to inte	rnet in the roaming status	3.	
WI-FI Settings					
Device Settings					Apply
Firewall	•				
Router Settings					
AP Station					